Size chart Saddle



All measurements are listed in CM.

Complete saddle set

	Bridle	
Al	38	
A2	45	A1 = Top of the head to bit (single side): shortest position
В	29	A2 = Top of the head to bit (single side): longest position
Cl	49	B = Length browband (measured straight across)
C2	55	C1 = Circumference noseband: shortest position
D	2,5	C2 = Circumference noseband: longest position
E	47	D = Width noseband including paddingE = Length flash strap in longest position

	Saddle		
А	33		
В	23	A = Length of the seat	
С	28	B = Width of the seat C = Length of the saddle flap	
D	27,5	D = Width of the saddle flap	

	y
-	Α
\int	
A	В
	C
<u>/ D </u>	
$\langle \rangle$	
\mathbf{X}	

	Girth	
А	100	• •
В	9	A = Length B = Width



E