

Size chart leg protection



All measurements are listed in CM.

Leg protection Air Mesh

	S	M	L	XL
A	22	25	27	29
B	25	27	29	30,5

A = Total height boot

B = Circumference at the widest point

